

- **Sound System**

Sl. No.	Description	Sl. No.	Description
1.	Speaker Box EAW line array , JBL, Peavey, QSC, Bose	11.	DVD Player (Sony)
2.	In ear monitor	12.	DJ Console (Denon)
3.	Amplifier Peavey, Studio Master, QSC Roland , Crown , Sound X Crest Audio	13.	Midi & CD Player (Sony)
4.	Equalizer DOD, Peavey, Roland, XTA	14.	Dat Player/Recorder (Tascam/Sony)
5.	Audio Mixer Sound Craft (16/32/48 Ch.) Mackie (16 & 24Ch) Peavey (6 / 8 / 12 / 16Ch)	15.	Mike Hand Cordless (UHF, Shure)
6.	Effect Processor Alesis, Digitech, Lexicon, Yamaha SPX 2000	16.	Mike Lapel Cordless (Senz / Shure)
7.	Compressor Limiter Alisis, DBX 160A, DBX 166, DOD 806	17.	Mike Lapel with Cord (Sony / Audt)
8.	Guitar Amps Roland JC-120, DB-115	18.	Microphone (SM – 52 /57/58)
9.	Key Board Amps Roland KC-550	19.	Shure Drum Kit Mike Set
10.	Deck Denon / Technica / Aiwa)	20.	Beta 52 A Mike
		21.	Mike Podium with Base (Shure)
		22.	Mike Boom (Sennh / Audiotech)
		23.	Mike Boundary (Shure)
		24.	Mike Vocal Head Set (Shure)
		25.	Snake Cable (Shure)
		26.	DI Box (DOD, Roland. BSS)
		27.	Head Phone (Sony / Koss)
		28.	Voltage Stabilizer (10 , 5 , 3 , 1Kv)

- **Light System**

Sl. No.	Description
1.	LED par
2.	Par Can 64
3.	Pulsar Pack
4.	Pulsar Controller
5.	Follow Spot (SGM) Mixer & Stand
6.	Scanner (SGM Victory 250)
7.	Scanner (SGM Galileo-IV)
8.	Scanner Controller (Pilot 1600,2000)
9.	Moving Head Wash
10.	Moving Head
11.	Sharpy Light
12.	City Color
13.	Sky Tracker
14.	Color Lab
15.	Smoke (Untary)
16.	Strobe (Big / Small)
17.	Moon Flower
18.	Laser
19.	Blinder

• Projection System & Camera Setup

1. LCD Projector Ansi-Lumens- 7000,6000, 5000, 4000,3000,2500, 2000 (Sony, Sanyo, Panasonic, Philips)	14. Laptop (Compaq , Toshiba , HP)
2. Screen Back Projection Size :- 4/6, 8/6, 9/12, 10/7.5, 16/12	15. Computer (P4) with Monitor (LCD /General)
3. Screen Front Projection Size :- 8/6 , 6/4	16. Over Head Projector Kinderman /GE
4. Plasma T.V. Panasonic & Samsung 48” ,40”	17. Slide Projector (Kinderman)
5. TFT Monitor	18. Video Mixer Data Video, MX-70, MX-50A, MX-Pro
6. T.V. Monitor Sony - 29” , 21” , 14”	19. Changer
7. Beta Player / Recorder Sony 2800, 2600	20. Extron & Kramer Switcher (4:1, 2:1)
8. U-matic Recorder (Sony 8800)	21. Splitter (4:1, 2:1)
9. DV Recorder (Sony 45P)	22. VGA Cable
10. DVC Pro	23. RCA Cable
11. VHS Recorder (Panasonic)	<u>Camera Setup</u>
12. DVD Player (Philips, Pioneer)	24. Camera Sony D30, PMW 150,
13. Black Magic (Live facebook & youtube)	25. Camera Monitor (Sony 9”)
	26. Clear Com
	27. LED Wall (P-3) Setup

- **Truss & Décor Setup**

Sl. No.	Description
1.	Truss Fitting
2.	Décor Setup